



# SADF

ARGENTINA Buenos Aires

## SADF

## San Fernando International Airport

S 34 27'3" / W 58 35'0"

10 ft.

AVGAS/JET

VORTAC

05/23

1801 m (5909 ft.)

### Contact Information

**Country:** Argentina  
**Headquarters:** Buenos Aires, Argentina  
**ICAO:** SADF  
**Service area:** Argentina and Southern Cone  
**Radio frequency:** 120.70 MHz  
**SITA:** N/A  
**Telephone:** +5411-5245-2442  
**Fax:** +5411-5245-2442  
**Online contact:** [info@premierair.com.ar](mailto:info@premierair.com.ar)  
**Website:** [www.premierair.com.ar](http://www.premierair.com.ar)

Welcome to Premier Air!


Our philosophy is simple: we take on the care and maintenance of your aircraft, ensuring the owners a unique and differentiated experience.

Our service is designed to provide you with peace of mind, safety and well-being.

My team and I will pay special attention to making your stay a success.

We hope to see you soon!

## San Fernando International Airport



## Ground Support Services

- 24-hour operation (prior notice)
- Covered hangar, 1900 square meters
- External platform, 2500 square meters
- Ramp, handling and cleaning services
- Fuel
- Aircraft dispatch
- Catering
- Meeting room
- Private offices
- VIP lounge for passengers
- VIP lounge for pilots
- Office bar and refreshments
- Restrooms, changing room and shower
- Car rental, transfers available
- 24-hour security – Closed-circuit TV

## Flight Services

- Flight plan and weather data
- Aircraft dispatch
- Migration and Customs



## ARGENTINA Buenos Aires

### SADF

S 34 27'3" / W 58 35'0"

05/23

1801 m (5909 ft.)

### San Fernando International Airport

10 ft.

AVGAS/JET

VORTAC

### City of Buenos Aires



### Airport



### Airport Location:

The main access from the Autonomous City of Buenos Aires (located 30 km to the Southeast of the Airport) is the Acceso Norte Highway – Tigre Branch. To access the terminal, take the exit of Provincial Route 202 (Avenida Hipólito Yrigoyen) connecting to the Acceso Norte Highway – Tigre Branch 600 meters to the left.

### Office Location:

Once you have reached the Airport terminal, turn right towards runway head 23. Follow the road to the end where you will find the entrance to the Premier Air Services hangar.

### Contact Information:

**Telephone:** +5411-5245-2442  
**Fax:** +5411-5245-2442  
**Email:** [info@premierair.com.ar](mailto:info@premierair.com.ar)  
**Website:** [premierair.com.ar](http://premierair.com.ar)

San Fernando International Airport  
Tigre Branch and Route 202  
Runway Head 23